

THIS RADIO INFORMATION INSTRUCTION SHEET CONTAINS SPECIFIC DATA THE FACTORY HAS PROGRAMMED INTO THE RADIO. THIS INFORMATION IS NEEDED FOR SERVICING THE RADIO.

MODEL: T84GXA7HA3AK RADIO NAME: NA FO: 3732020112055 004

MDC UNIT ID: NA MDC PRETIME: NA EMERGENCY REVERT CHANNEL: NA

FIXED PRIORITY SCAN CHANNEL: NA MAX ORDERED CONV CHANNELS: NA

QC II CAPCODE: NA CODE A: NA CODE B: NA CODE C: NA CODE D: NA

OPTIONS:

SYSTEM INFORMATION

CONVENTIONAL

SYS/ ZONE	MODE/ CH	RX FREQ	TX FREQ	RX CODE	TX CODE	PR1	PR2	TO	P I	D I	S I	S S	D S	D E	Q E	P C	M R	D C	S Q
1		453.0500	453.0500	CSQ	CSQ	~	~	060	N	~	N	~	Y	~	Y	E	S		

- 1 -SYSTEM SELECT POSITION
- 1-I TYPE I TRUNKING SYSTEM
- 1-II TYPE II TRUNKING SYSTEM
- SYSID -SYSTEM ID FLEET (GROUP) ID/
PERSONALITY ID / CALL ID / SITE ID/
SYSTEM NAME FLEET (GROUP NAME)
- SUBFL(TLKGR)/ -SUBFLEET OR TALK GROUP LIST
- MODE FL= FLEET CALL
*= ANNOUNCEMENT CALL
- CCFQY -CONTROL CHANNEL FREQUENCIES IN MHz
- FSFQY -FAILSOFT CHANNEL FREQUENCIES IN MHz
- SCANM -LIST OF SUBFLEETS OR TALK GROUPS TO BE
SCANNED 01-A = SYSTEM 01,
SUBFLEET/TALK GROUP A
- RX FREQ -RECEIVER CHANNEL FREQUENCIES IN MHz
- TX FREQ -TRANSMITTER CHANNEL FREQUENCIES IN MHz
- RX CODE -PL, DPL, CSQ OF THE RECEIVER CHANNEL
PL= PRIVATE-LINE DPL= DIGITAL PRIVATE-LINE
CSQ= CARRIER SQUELCH CODE
- TX CODE -PL, DPL, CSQ OF THE TRANSMITTER CHANNEL
- PR1 -PRIORITY 1 SCAN
- PR2 -PRIORITY 2 SCAN

- OPTION\$TN EFFECT (Y= YES N= NO -= NOT APPLICABLE)
- AM - AUTOMATIC MULTIPLE SITE SELECTION
- CA - CALLALERT
B= ENCODE/DECODE D=DECODE L=LIST ONLY
E= ENCODE N= NO U= UNLIMITED
- CT - CONNECT TONE FREQUENCY IN Hz
- DE - DIGITALLY ENCRYPTED
- DI - DPL INVERT ON TRANSMIT
- DR - DYNAMIC REGROUPING
- DS - DPL INVERT ON SYSTEM SEARCH
- EA - EMERGENCY ALARM
- EC - EMERGENCY CALL
- ET - EMERGENCY TACTICAL
- FS - FAILSOFT
- LO - LOCAL SITE UNIT
- MDC - MOTOROLA DATA COMMUNICATION
E= ENABLE D= DISABLE
- MS - MESSAGE
- PC - PRIVATE CONVERSATION
D=DISPATCH M=MULTIPLE N=NO L=LIST ONLY
R=RECEIVE E=ENHANCED S=SINGLE U=UNLIMITED
- PI - PHONE INTERCONNECT
- PR - PAC RT D= DISABLE E= ENABLE
- PT - PUSH-TO-TALK IDENTIFICATION
- QC - QUICKCALL D= DISABLE E=ENABLE
- SA - SILENT ALARM *
- SF - FAILSOFT BY SUBFLEET (TALK GROUP)
- SQ - AND SQUELCH A= AND S= STD
- SS - SYSTEM SEARCH & LOCK
- ST - STATUS
- TO - TIME-OUT-TIMER IN SECONDS
- TS - TRUNKING SUBFLEET/TALK GROUP SCAN